

This procedure for “*Mercedes remote key blanking Pin installation*” was prepared by Polmex, Western Australian innovative Engineering Company, specializing in design and manufacture of special purpose Silicone products. Supplying to the market Silicone Buttons for worn out remote keys of various makes and models: Mercedes, Toyota, Ford, Mitsubishi, Hyundai, Land Rover, Holden, Peugeot ...*and more*

For Orders please visit us on line at www.polmex.com.au

Mercedes Blanking Pin Installation:



If the roll-pin from your remote is missing, simply press this silicone blanking pin in to:

- reduce key blade rattling and
- fill in the hole left by the lost pin to end up with better looking remote

