

This procedure for “*Toyota Prius, RAV, VERSO remote key – Worn out button Replacement instructions*” was prepared by Polmex – Western Australian manufacturer of Silicone Button Replacements for remote key controls of various car makes and models: Land Rover, Range Rover, Toyota, Mitsubishi, Kia, Holden, Commodore, Ford, Hyundai, BMW ...and more

For Orders please visit us on line at www.polmex.com.au



- ❑ To remove old rubber pad, pre warm it with the hand held hair drier.

It will make rubber more pliable and easier to remove



With flat screwdriver lift sides of the soft rubber pad and remove it from the shell. Do not insert screwdriver inside the shell as you may damage electronic switches.

Make sure you do not damage **hard plastic webbing** that separates electronic switches.

Once soft part is removed you should end up with remote looking like the picture to your left side. **Long hard plastic** part should remain intact.

Please make sure that **all grooves** are free of old rubber before you start fitting new pad in.



Start fitting pad from the **top (lock button cut out)** by slightly bending and sliding it under the sides of the cut out.



Once first button sits in properly in the cut out, you will repeat the same fitting process for the second cut out.



Next you will be fitting in remaining, long part of Silicone pad.



To fit it in properly use your thumb and apply combined rubbing and pressing movements to press the web into the grooves.



Once your new Silicone pad is fitted in your remote is ready for use. No re-programming is needed.