

This procedure for *“Toyota, Yaris, Avalon, Camry, Avensis, Hilux, Prado, Echo remote key – Worn out button replacement procedure”* was prepared by Polmex – Western Australian manufacturer of Silicone Button Replacements for remote key controls of various car makes and models: Land Rover, Range Rover, Toyota, Mitsubishi, Kia, Holden, Commodore, Ford, Hyundai, BMW ...and more

For Orders please visit us on line at www.polmex.com.au



Position flat screwdriver in a small slot at the top of your remote and twist it, so detachable part moves away from key part.



Separate back part of the cover from the key and remove electronic board.



Silicone buttons will be fitted from inside of the remote. Simply press fit silicone buttons in. Make sure that buttons are fitted flat with the surface of the plastic shell.



Place electronic board back in remote, cover it with bottom part of the shell and close it.



No swapping components and **No reprogramming is need it.** Remote will work straight away. Your remote with fitted in silicone repair buttons will look like the one the side.