

This procedure for “*Toyota Prado, Corolla, Yaris, Avensis remote key – Worn out button replacement procedure*” was prepared by Polmex, Western Australian innovative Engineering Company, specializing in design and manufacture of special purpose Silicone products. Supplying to the market Silicone Buttons for worn out remote keys of various makes and models. Commodore, Ford, Mitsubishi, Land Rover, Hyundai, Toyota Nissan, BMW, Holden Peugeot...

For Orders please visit us on line at www.polmex.com.au

Toyota Prado, Avensis, Yaris, Corolla :



Button Replacement Procedure

(Can be done from outside of remote or after opening from inside)

1. Open remote by unscrewing screw on the back of the cover.
2. Remove old, worn through buttons accessing it from inside of remote.
3. Press fit new silicone buttons into the front cover from inside. No gluing needed.
4. Test your remote with the new buttons fitted in.

Once buttons replacement is finished, remote will work straight away with **no need for re-programming.**

